

## **Historic, archived document**

Do not assume content reflects current scientific knowledge, policies, or practices.





# BETTER STRAINED ROSIN MORE MONEY

## TO TURPENTINE OPERATORS:

See that your strainers—all three of them—are big enough and in good condition. Poorly made, worn-out strainers cause dirty rosin.

Make your strainers carefully of 1½-inch lumber. Have your wires tight and even, with no pockets or wrinkles.

Keep hoop-iron strips straight and flat or they will let dirt get through where the batting is not held down properly.

## DON'T CHECK FLOW WITH SMALL STRAINERS

Set still high enough to use three strainers, one for trash, one for dirt, one for batting—each makes money for you.

Each strainer must be large and deep enough to allow the whole charge of rosin to be drawn in the shortest possible time.

Checking the flow is almost certain to scorch rosin left in the still. This may lower the grade of the whole charge.

Vats should be at least 15 feet long and 4 feet wide at top, inside measurements.

## CLEANLINESS ALWAYS PAYS

Handle strainers carefully.

Keep strainers and edges of vats clean. Remove all dirt from strainer after each straining.

Whip the bottom strainer thoroughly but carefully after each charge.

## LET US HELP YOU TO BETTER ROSIN



WRITE TO  
U. S. DEPARTMENT OF AGRICULTURE  
NAVAL STORES INVESTIGATIONS  
WASHINGTON, D. C.

